

All-in-on LANC Remote

One model for all cameras, one button for all functions

2007



Water/dust/Mud proof Design

All-in-one remote control makes one LANC remote control for all video cameras and one button for all functions possible. It works for all old models of Sony or Sony LANC compatible video camera, new DVD and Hard Disk video cameras with a 2.5mm LANC jack. You don't need concern compatibility problems and complicated button combinations to control your video camera. Long LANC cable makes it easy to store you video camera in safe place while focusing on your sport activities. There is no need to access the video camera buttons directly for recording and standby or power on/off. It can extend the video camera battery life. Only one simple multi-color LED for video camera status feedback, such as recording, standby, low battery and low tape status. The LANC extension is also available.

Zowietek Electronics, Ltd.
Pudong, Shanghai, China
<http://www.zowietek.com>
sales@zowietek.com

All-in-one LANC Remote Control

One model for all cameras

One button for all functions

Installation

◆ Turn off video camera, plug 2.5mm plug of LANC remote control in the LANC socket on the video camera. Never insert or eject LANC remote in or out when video camera is in operation.

Operation

◆ Power On: Hold down the control switch until LED is GREEN. The video camera power switch should remain in ON mode during this operation. The LED will be GREEN and then off in one second. Then, the LED will flash the times of current mode to indicate the mode status.

◆ Power Off: Hold down the control switch for at least 2 seconds and the LED turns to quick RED flash. Release the control switch and the video camera turns off.

◆ Recording and Standby: Press the button briefly and let go. The video camera starts recording. LED will change to RED. Press the button again will stop recording and standby. The LED will change to GREEN.

◆ Display version: Three versions: version 1, 2 and 3, are supported. Power off video camera by LANC remote, then power on video camera again meanwhile holding the button down at least 3 seconds but less than 6 seconds until the LED turns QUICK GREEN flash. The RED LED will flash the times of current version to indicate the version status.

◆ Change version: Power off video camera by LANC remote, then power on video camera again meanwhile holding the button down at least 6 seconds until the LED turns QUICKER GREEN flash. The RED LED will flash the times of current version to indicate the version status.

For version 1, Camera, Photo and VCR/Player modes can be controlled independently but camcorder will restore to Camera when power up again each time. Version 1 can work with any Sony V8/Hi8/DV/DVD/HDD or compatible camcorders in camera mode.

For version 2 and 3, the LANC remote control will override the video camera power switch to set the video camera in VCR/PLAYER mode automatically when the LANC remote control connected. This is very useful in various sports activities.

■ ■ STEAD GREEN indicates that the video camera is in Camera/Player/VTR mode or in stand-by and ready to record.

■ ■ STEAD RED indicates that the video camera is in Recording.

■ ■ QUICK RED FLASHING indicates the video camera will be turned off once button is released.

■ ■ QUICK GREEN FLASHING indicates the LANC mode will be changed to next one once the button is released.

All-in-one LANC Remote Control

One model for all cameras

One button for all functions

■ ■ SLOW GREEN FLASHING indicates that the video camera is ready or standby but has one of following problems: low battery, less than 5 minutes of tape remaining, record protected tape.

■ ■ SLOW RED/GREEN FLASHING indicates that the video camera is recording but has one of following problems: low battery or less than 5 minutes of tape remaining.

■ ■ SLOW RED FLASHING indicates that video camera is not in right mode, not ready to start recording or no tape in the video camera.

■ ■ FATAL ERROR found.



Dimension

Control Unit: 18 x 30mm

LANC cord: 100cm

LED cord: 50cm optional