


ErgoEase Remote Control



Button	Operation	Up	Down	Left	Right
+	OSD Menu	Up	Down	Left	Right
$F1(S) / \text{C}$ +	P/T Control	Tilt Up	Tilt Down	Pan Left	Pan Right
$F1(L/D) / \text{Z}$ +	Z/F Control	Zoom In	Zoom Out	Focus Far	Focus Near
$F0(S)$ +	Recall Presets	Preset 1	Preset 3	Preset 4	Preset 2
$F0(L/D)$ +	Set Presets	Preset 1	Preset 3	Preset 4	Preset 2
+	Exposure(Auto)	EV+	EV-	Gain Limit-	Gain Limit +
+	Exposure(AAE)	IRIS +	IRIS -	Gain Limit-	Gain Limit+
+	Exposure(Manual)	IRIS +	IRIS -	Shutter-	Shutter+
+	Exposure(SAE)	Shutter +	Shutter -	Gain Limit-	Gain Limit+

- * Each Ergoease remote control needs to correspond to the PTZ Camera with the same SN.
- * If ErgoEase Remote Control remains inactive for two hours, it will enter sleep mode automatically. To wake it up, just press any keys excluding Joystick.
- * S: Short Press, L: Long Press at least 2s, D: Double Click
- * Long Press: Restore to default