



Add a VISCA Over IP Camera to ZowieKBD

Click  to add manually or click  ->Device Management->CAM List->Add to add manually.

Use the up, down and top button of the joystick to move the cursor and modify the parameters.

Add Camera	
Name	Camera >
Type	VISCA over IP(UDP) v
Cam	VISCA over IP(UDP)
IP Addr	VISCA over IP(TCP)
Port	ONVIF
Stream Addr	rtsp://192.168.1.5
Add	ONVIF VISCA PELCO D

Select the type as VISCA over IP (UDP)/VISCA over IP (TCP), and the Cam number can be specified or automatically assigned in the order in which it is added.

Add Camera	
IP Addr	192.168.1.148 >
Port	1259 >
Stream Addr	rtsp://192.168.1.148:554/sub/1 >
RTSP Auth	Off >
RTSP Password	admin >
RTSP Username	admin >
Add	

Enter the IP address and UDP/TCP port number of the camera to be controlled (ZowiePTZ default port TCP: 5230; UDP: 1259)

Enter the correct RTSP address and RTSP authentication for preview.