


## Interface Description



NUM	Name	Function
1	TF Card Port	For firmware upgrading.
2	Line Out Port	Monitor the current camera audio when the screen is single grid.
3	HDMI Out Port	Output the video to an external monitor.
4	USB Port	For firmware upgrading.
5	RS232 Interface	Connect RS232 cable for controlling Cameras.
6	RS422/RS485 Interface	Connect RS232 cable for controlling Cameras.
7	Tally / Contact (GPI I/O Connector)	Tally control interface.
8	LAN Interface	Connect the ZowieKBD to a network/power supply.
9	DC In	Power supply.
10	Power Button	Power on/power off the ZowieKBD.