

Shortcut Buttons

In certain interfaces, users can use long press/combination keys to perform some shortcut operations.

Buttons	Function	Description
Long press 	Hide/show camera information	
Press 	View basic keyboard information	Use in single grid/four grid interface preview
Long Press 	Modify the current camera parameters	Use in single grid/four grid interface preview
Long press 	Enter group management interface	
Number + 	Quickly switch current group	
Number1~4 + 	Quickly switch current control window	Use in four grid interfaces
Press 	Enter camera/group list for quick selection	Use in single grid/four grid interface
Press 	Enter the camera's OSD menu	Takes effect when the camera's OSD menu is awakened