



Add a Sony VISCA Camera to ZowieKBD

Method 1: Search for Sony VISCA Camera (Recommended)

Click  and select Sony VISCA protocol to search or click  ->Device Management->Search and select Sony VISCA protocol to search.



Sony VISCA Discovery			
1	ZowiePTZ-00001	192.168.1.23	Cam20
2	Minrray	192.168.1.32	Cam21
3	ZowieBox-23455	192.168.1.45	-
4	ZowieBox-SDI-00001	192.168.1.47	-
5	ZowiePTZ-66128	192.168.1.64	-
6	ZowiePTZ-2212	192.168.1.76	-
Add		Check All	Search


After the search is completed, use the up, down and top button of the joystick to select the camera you want to add. A " ✓ " sign will appear in front of the selected camera .

Use the left, right and top button of the joystick to operate Add/Check All/Search below.

After clicking to add a single camera, please enter the correct RTSP address and RTSP authentication. (This step is not required when adding Sony VISCA cameras in batches)

192.168.1.148(ZowiePTZ-66148-Sony VISCA)		
Name	Camera	>
Cam	Auto	✓
Stream Addr	3:554/sub/av	rtsp://192 >
RTSP Auth	Off	>
RTSP Username	admin	>
RTSP Password	admin	>
Add		

Method 2: Manually add Sony VISCA camera

Click  to add manually, or click  ->Device Management->CAM List->Add to add manually.

Use the up, down and top buttons of the joystick to move the cursor and modify the parameters.

Add Camera		
Name	Camera	>
Type	Sony VISCA	✓
Cam	Auto	✓
IP Addr	192.168.1.148	>
Stream Addr	p://192.168.1.148:554/sub/av	>
RTSP Auth	On	>
Add		

Change the Type to Sony VISCA, enter the IP address and RTSP URL of the camera to be controlled, and select the correct RTSP authentication.

The Cam number can be specified or automatically assigned in the order in which it is added. Click Add to complete the addition.

Tips:

Go to page 30 to see how to preset the RTSP suffix for quick addition